

Frigidaire

Factory Parts Catalog


Product No.	FDB520RHB0	FDB520RHS0
Series	Built-in 24"	Built-in 24"
Color	black	white
Owner's Guide English	154659801	154659801
Owner's Guide Spanish	154659803	154659803
Owner's Guide French	154659802	154659802
Service Data Sheet	154737301	154737301
Energy Guide	154678526	154678526
Installation Instructions	154427301	154427301
Market	North America	North America

24-INCH BUILT-IN DISHWASHER

Model No.
FDB520RH

Publication No.
5995529012
08/11/18
(EN/SERVICE/ECL)
821

CONTROL PANEL




CONTROL PANEL

Model Index: **A** FDB520RH (FDB520RHS0)
B FDB520RH (FDB520RHB0)

POS. NO	PART NO.		DESCRIPTION
1	154645201	A -	Panel, control, white
1	154645203	- B	Panel, control, black
2	154737601	A -	Overlay, control panel, white
2	154737603	- B	Overlay, control panel, black
3 #	154718501	A B	Control, board
4	154552101	A B	Cover, control
8 #	154737701	A B	Switch Assembly, 7 button
20	154433001	A B	Vent assy, static dry
20*	154436201	A B	Screw, dry duct, (3)
33	154553501	A B	Gasket, cover
* #	154646301	A B	Harness, wiring, main
* #	154738201	A B	Harness, wiring, switch, to main harness
*	154227501	A B	Thermistor
*	154678526	A B	Energy guide label
*	154294701	A B	Screw, #7 plas .375, (6), disp. assy.
*	154409401	A B	Screw, #8-18 x .375


DOOR



P30B0045

DOOR

<i>Model Index:</i> A FDB520RH (FDB520RHS0) B FDB520RH (FDB520RHB0)			
POS. NO	PART NO.	DESCRIPTION	
1	154430501	A	B
1A	154325201	A	B
2	154093301	A	B
3	154691401	A	B
3A	154691301	A	B
*	154647101	A	B
*	154686401	A	B
5	154079601	A	B
7	154494601	A	B
9	154574401	A	B
9*	154294701	A	B
10	154103702	A	B
12 #	154556701	A	-
12 #	154556703	-	B
20	154538301	A	-
20	154538303	-	B
20*	5304428306	A	B
22	154388801	A	B
49	154576501	A	B
51	154320301	A	B
*	154409401	A	B
		Screw, #8-18 x .375	

TUB


P30U0024

TUB

Model Index: **A** FDB520RH (FDB520RHS0)
B FDB520RH (FDB520RHB0)

POS. NO	PART NO.	DESCRIPTION	
1 #	154729301	A	B
2	154662601	A	B
3 #	154561001	A	B
4	154200602	A	B
5	154333902	A	B
6	5303943103	A	B
22	154577401	A	B
23	5303318539	A	B
24 #	154606701	A	B
25 #	154209701	A	B
28	154408701	A	B
29 #	154290204	A	B
30	154241101	A	B
30*	154297701	A	B
*	154685101	A	B
*	5300807270	A	B
*	154041001	A	B
*	154200601	A	B

MOTOR & PUMP




P30M0041

MOTOR & PUMP

Model Index: **A** FDB520RH (FDB520RHS0)
B FDB520RH (FDB520RHB0)

POS. NO	PART NO.	DESCRIPTION	
1	154247601	A	Heater
1*	154106202	A	B
1*	154289801	A	B
2	154479601	A	B
10	154245501	A	B
13	154246801	A	B
14	154365902	A	B
16	154246502	A	B
24	154568001	A	B
24A	154313601	A	B
24A*	154252001	A	B
32	154406601	A	B
32A	154406401	A	B
40	154348401	A	B
40	154348502	A	B
40*	154106801	A	B
40*	154380601	A	B
54	154234401	A	B
55	154595901	A	B
55*	5303316032	A	B
58	154246402	A	B
59	154246901	A	B
59A	154247001	A	B
60 #	154640201	A	B
60*	154426201	A	B
60*	154581501	A	B
61	154606801	A	B
62	154294101	A	B
63	154252201	A	B
64	154252301	A	B
65	154252401	A	B
66	154252701	A	B
70 #	154700101	A	B
*	154200601	A	B
		Screw, #10-16 x 3/8	


FRAME**P30F0022**

FRAME

Model Index: **A** FDB520RH (FDB520RHS0)
 B FDB520RH (FDB520RHB0)

POS. NO	PART NO.		DESCRIPTION
3 #	154637401	A B	Valve, water
4	154669301	A B	Brace, front frame
8	154589401	A -	Toeplate, adjustable, white
8	154589403	- B	Toeplate, adjustable, black
9	154589501	A -	Kickplate Assy, white
9	154589503	- B	Kickplate Assy, black
10	154371301	A -	Screw, Phillips head, white
10	5300808658	- B	Screw, #8A x .375", black
11	154200701	A B	Screw, #10-32 x 3/8
11A	154200601	A B	Screw, #10-16 x 3/8
15	154571101	A B	Leg, leveling, (4)
20	154597001	A B	Cover, junction box
*	154041001	A B	Screw, plask #1, 10-10 x 9/16
*	154200602	A B	Screw, 10-16 x 3/8, hex
*	154409401	A B	Screw, #8-18 x .375

RACKS



P30R0111

RACKS

Model Index: **A** FDB520RH (FDB520RHS0)
 B FDB520RH (FDB520RHB0)

POS. NO	PART NO.	DESCRIPTION	
1	154336020	A	B
2	5300808994	A	B
3	154331502	A	B
4	154522901	A	B
5	5300809927	A	B
6	154597801	A	B
7	154174502	A	B
8	154304001	A	B
9	154251801	A	B